1. I have forgotten the administrator username and/or password.

To reset the administrator username and password, Press and hold down the RESET BUTTON for 5 seconds. Release the power button and the username and password will be reset back to the factory default administrator username and password.

Default administrator username: **admin** Default administrator password: No password

2. IP Address configuration

Check whether IP address of the IP Camera server shares the same subnet as your work station: Click My Computer > Control Panel>Network & Dial-up Connections > LAN > Attributes >Internet Protocols (TCP/IP), and check IP Address and Subnet Mask. Make sure they are in the same subnet when configuring IP Camera IP address manually. Unable to access IP Camera via web browser

3. Network Configuration

Double Check to ensure that your HTTP server software isconfigured and running properly. If you're running any firewall software, make sure it's allowing inbound connections to port 80,Also,if you happen to be using a cable/DSL router, make sure you've set up port forwarding properly. (consult your router's documentation for more information). If none of these seem to be the problem, it's also possible that your ISP is blocking inbound connections to port 80 -many IPS is have done this because of internet worms such as Code Red, If this is the case, you 'll have to setup your HTTP server on an alternate port (such as 8080).

4. Flush Arp Buffer

When cable network and wireless network of the device both are fixed IP address. There a problem you may encounter is can search the camera IP but can't open the camera web page. you may try to use flush arp buffer.

5. No pictures Problems

The video streaming is transmitted by the ActiveX controller. If ActiveX controller isn't installed correctly you will see no video image.

download ActiveX controller and set the safety property of IE in the PC when you view it first time: "IE" browser "Tool" -"Internet Proper- "Security -"Custom Level" ActiveX control and Plug-ins" three options of front should be set to be "Enable", The ActiveX programs read by the computer will be stored. as follows:

Enable: Download unsigned ActiveX controls

Eable: Initialize and script ActiveX controls not marked as safe

Enable: Run ActiveX controls and plu-ins

6. Problems with network bandwidth

The image frame rate is subjected to the following factors: network bandwidth

PC performance, network environment and display preference setting (brightness, theme, etc.)

the number of visitors (Too many visitors will slow down the image frame rate.)

choice of switch or hub (Use a switch for multiple IP Camera Servers rather than a HUB.).

7. Why pop-up the prompt "Fail to connect to the device..."?

This prompt only appeared in the case of using multiple cameras.

Enter the **Multi-Device Settings** page (login as administrator) to check the Device setting is correct or not.

When one of the multiple cameras disconnected, the color changed to yellow and pop-up the prompt "Fail to connect to the device...".

8. Can't access the IP camera in the internet?

- A. ActiveX controller is not installed correctly
- **B.** The port IPcamera used is blocked by Firewall or Anti-virus software.Please change a port number and try again.
- C. Port mapping is not success. You can do port mapping by two ways:

Enter setting page of the router which ip camera connect with to enable UPNP function. Enter ip camera "**UPNP Settings**" to enable UPNP and make sure the state is "UPNP success". If your router has the Virtual Map function.Enter router setting page, add ipcamera's IP and port to the Virtual map list.

9. Using a router to access the Internet

Using a router to access the Internet by shared ADSL If a router is set for dial-up Internet access, it is not required to set ADSL dial-up account and password on the IP Camera.



10. Static IP user

Static IP user is not need to use DDNS for remote access. When finished the setting of the IP Camera in LAN, you can access the Camera directly from Internet by the WAN IP. You can obtain the WAN IP by two ways.

Obtain the WAN IP from some Website

You can discover this easily by opening on a computer using the same connection as the IP camera and entering this address <u>http://www.whatismyip.com.The</u> page at this address will show you the current WAN IP.



Obtain the WAN IP address from the router

Take the WRT54G router of LINKSYS for example,

1) Obtain the IP address of the router(LAN gateway address), user name and password for logon to the router from the network administrator,

2) Enter the LAN IP address of the router(LINKSYS WRT54G default:192.168.1.1) in the

address bar of the IE to log on to the router; Open the **Status** page to find out the WAN address of the router. In this example, the address is 116.25.51.115.

LINKSYS [®] A Division of Cisco Systems, Inc.						Ferror	ere Version: +4 20 f	
Status				٧	Vireless-G Broad	Iband Router	WRTS4GL	
	Setup	Wireless	Security	Access Restrictions	Applications & Garning	Administration	Stelus	
	Router	Local	Network	Wreless				
Router Information	Firmwo Curren MAC A Router Host N Domain	we Version (Time: ddress: Name: ame: Name:	v4.30.5, Apr. 27, 21 Not Available 00:0C:41:00:01:71 WRT54GL	105		Firmware Ver Router's currer Current Time Ime, as you se Tab MAC Address Router's MAC A by your ISP. Router Hame.	relian. This is the 4 firmware. 	
Configuration Type	Login T P Addr	Ype:	Automatic Config	uration - DHCP		specific name t which you set Tab More	or the Router, on the Setup	

11. For example: Register procedure from a DDNS web

Step1: enter http://www.dyndns.com/ and Create Account :



Step2: enter your information

🔿 Dyr	DNS	Users Pass Login					
	About Services Account	Support News					
Ny Account	Create Your DynDNS Accourt	ıt					
Create Account							
Login	Please complete the form to create your free DynDNS Accourt	t.					
Lost Password?	- User Information						
	Username: topetropauk						
Search	E-mail Address: hawkannee.com						
	Coofirm E-mail Address: however the com						
Search	Password: ••••••• Your people of the bar is characters and cannot be the same as your us not dipole a parent of the is a common word, or can otherwise be easily guessed.						
	Confirm Password:						
	About You (optional)						
	Providing this information will help us to better understand our for your help!	customers, and tailor future offerings more accurately to your needs. Thank					
	How did you hear about	We do.not.ad your account information to anyone, including your e-mail address.					

Step3: After a minute, you will receive a E-mail from **DynDNS Support** and it will give you a confirmation address

(e.g.https://www.dyndns.com/account/confirm/vXMVT78-KvehydmKMWH5kg)

Step4: When the Account Confirmed, login and start using your account. Choose **Add Host Services** and enter **Add New Hostname** page.



Add New Hostname

Note: You currently don't have Account Upgrades in your account. You cannot use some of our Host Service features. Please consider buying Account upgrade that make this form full-functional and will add several other features. Learn More...

Wildcard: Yes, alias "*.hostname.domain" to same settings.	
Service Type: Host with IP address 2	
 WebHop Redirect 	
 Offline Hostname 	
	0
IP Address: 116.30.19.113 3	
Lite auto detected IP address 116.30.19.111	
TTL value is 60 seconds. Edit TTL.	
Mail Routing: 🔲 Yes, let me configure Email routing.	

Step5: On the Add New Hostname page.

1) input your Hostname.

2) choose Host with IP address

3) click <u>Use auto detected IP address xxx.xx.xxx.</u> Then click **Create Host**.

Host Services	Add New Hostname - Host Update Lo		
	Hostnam	eterstindwk.dyndns.org created.	
Hostname	Service	Details	Last Updated
and the sk. dyndns.org	Host	116.30.19.113	Apr. 02, 2008 2:43 AM

Step6: Now you obtained a Dynamic Domain Name(Figure 4.6),and can use it in the **DDNS Service Settings**