((gtx

ZEPHYR

Compact Haze Machine

Item ref: 160.494UK User Manual

¢ qtx

Version 1.0

Caution: Please read this manual carefully before operating Damage caused by misuse is not covered by the warranty



Introduction

Thank you for purchasing the ZEPHYR compact haze machine. This product has been designed to provide controlled haze effects for stage productions and themed events. Please read and keep this manual in order to achieve the best results from this equipment and avoid damage through misuse.

Unpacking

The product should arrive with you in good condition with the following components.

- ZEPHYR haze machine
- Wireless remote control & keyfob
- Mains lead(s)

If you find any accessory is missing or the machine has arrived with any problems, please contact your local dealer at once. Please keep the original package and invoice for any possible replacement or returned demand.

Warning

To prevent risk of fire or electric shock, do not expose electrical parts to rain or moisture. If liquids are spilled on areas other than inside the fluid tank, disconnect the mains, allow the ZEPHYR to dry out and have it checked by qualified personnel before further use. Avoid any impact, dropping or extreme pressure to the housing. No user serviceable parts inside - do not open the case. Allow the ZEPHYR to acclimatize to room temperature before operating.

Placement

The ZEPHYR has a built-in fluid container and should be operated in an upright position. Ensure that the ZEPHYR is positioned on a stable, non-slip surface.

Safety

- Check for correct mains voltage and condition of IEC lead before connecting to mains
- This unit must be earthed
- This unit uses a heating element be aware that parts of the housing may be hot in use!

Cleaning

- Use a soft dry or slightly damp to clean the casing
- Do not use strong solvents for cleaning the housing
- Clean the haze mechanism periodically by operating with distilled water instead of haze
- It is also recommended to use fog machine cleaning fluid (160.670UK) periodically

Recommended fluid

For the ZEPHYR haze machine, we strongly recommend the following fluid which has been specifically formulated to perform best with any heater based haze machines.

QTX ref code	Description	Size
160.591UK	High quality professional haze fluid	5 Litre
160.596UK	Eco haze fluid	5 Litre

Use power supply with Earth connection and adequate current capacity for the unit

Use the plug to connect to the main power supply as follows:

Wire	Connection	International signal
Brown	Live	L
Blue	Neutral	Ν
Yellow /Cyan	Earth	

Rear panel



- 1 LED display
- 2 4 button control panel
- 3 RF remote receiver connection (5-pin DIN)
- 4 DMX input (3-pin XLR)
- 5 DMX output (3-pin XLR)
- 6 IEC mains inlet & fuse holder

Setting up

- 1. Unpack the ZEPHYR unit.
- 2. Unscrew the top cap of the tank and remove to fill with haze fluid.
- 3. Replace the bottle and screw the cap securely, making sure that the pipe is fed down to the bottom of the bottle to ensure a consistent flow of fluid.
- 4. If required, connect the remote receiver via the 5-pin DIN socket on the rear panel.
- 5. Set the DIP switches on the side of the RF receiver to respond to the required button on the keyfob transmitter (e.g. setting DIP switch 1 on will mean that haze will be produced when button 1 is pressed on the keyfob)
- 6. If DMX is to be used for control, connect the DMX signal from the controller to the DMX IN XLR connector. Any further DMX controlled units may be connected via the DMX OUT XLR connector.
- 7. Connect the IEC mains plug and switch the power on.
- 8. Heat up time is as little as 35 seconds before the ZEPHYR is ready to use.

Operation

To operate the ZEPHYR in standalone mode, use the 4-button control on the rear panel beneath the LED display as follows.

Press MODE	Press ▲▼ and ENTER	Function
R	800 I - 85 I2	DMX start address 001 to 512
o	o000 - o255	Haze output 0 – 100%
F	F000 - F255	Fan speed slow to fast

Adjust the fan speed and output to the required output consistency.

If the remote receiver is connected, then this will enable wireless on/off control of the haze output from the buttons as set on the DIP switches.

It is important to note that the Zephyr uses an efficient fast heating element and will take around 1 minute to clear the fluid from the heater after hazing has stopped. An LED above the output aperture is lit when hazing is activated to show the status.

If the display is showing the DMX address, the ZEPHYR will operate from DMX control as follows.

Channel 1 (start address)	0	Off
Channel 1 (start address)	1-255	Haze output 1-100%
Channel 2 (start address + 1)	0-255	Fan speed slow to fast

Specifications

Power supply	230Vac, 50Hz (IEC)
Power	300W
Tank capacity	1.2 litre
Haze output (approx.)	3,000 CuFt (68m ²) per minute
Reheat time	35 seconds (min.)
Controls	Output (0-255), Fan speed (0-255)
Fuse	F3AL 250V
Remote control	RF keyfob & receiver (5-pin DIN)
Remote control frequency	433MHz
DMX channels	2 (output & fan)
DMX connection	3-pin XLR in & out
Dimensions	253 x 336 x 155mm
Weight	3.56kg

Troubleshooting

Warning: Hot components! ... Switch off and allow to cool before touching the unit.

	Check mains voltage is correct and socket is switched on
No light on mains	Check IEC lead is OK and connected properly
switch or remote	Check mains fuse in IEC connector and fuse in plug top
	If fuse blowing repeatedly, refer to qualified service personnel
	Check fluid level in tank
Croon light is on but	If fluid is OK and pump working, the lines may be blocked
Green light is on but no haze output on	Check that output is not set to zero on the control panel
manual or	Check that output is not switched off on the keyfob remote
continuous mode	If blocked, clean with fog machine cleaner & distilled water
continuous mode	Check that if DMX mode is selected, the DMX channel is correct
	In DMX mode, check that haze output is not set to zero



CE Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines

Errors and omissions excepted. Copyright© 2018. AVSL Goup Ltd

シテリ				ETTECUS P	Effects Fluid Chart			
Bubble Fluid								
Stock Code	Volume	Description			Res	Results		For use with
160.574UK	1 Litre	Buddle fluid			Licht long lo	cting hubbler		
160.575UK	5 Littre	_			LIBRIL, IORB-14	Lignt, Iong-Iasting pupples		160.462UK, 160.560UK 160.562UK, 160.563UK
160.576UK	1 Litre	IIV hickle fluid			iaht hubbler which alow in UV liaht	ch clow in UV lich	+	160.564UK
160.577UK	5 Littre			-	רופוור מתממובא אווו		=	
Snow Fluid								
Stock Code	Volume	Description			Res	Results		For use with
160.578UK		Snow fluid		High cuality sho	High cruality snow fluid Lasts 30% Ionger than other standard fluids	longer than othe	r standard fluids	160 56511K 160 56911K
160.579UK	5 Littre							
Fog Fluid								
					Res	Results		
Stock Code	Norme	nescription	COLOUI	Dispersion	Density	Stability	Fog colour	FOI USE WILLI
160.643UK	1 Litre	 Standard fog fluid 	Yellow	Quick	Light	Low	White	VIITAA OAT VIICAA OAT VIICAA OAT
NU28C.UOL	2 LITTE							TOU-4320V' TOU-4330V' TOU-40TOV
160.587UK 160.588UK	1 Litre 5 Littre	- High grade fog fluid	Orange	Slow	Medium	Good	White	or any machine up to 900W
160.644UK	1 Litre	الأعام متناقات فمع فانتلط	daid		4211	100	Thick	110 ACC 110 ACC 110 ACC 120
160.583UK	5 Litre		4	MOID	10	2000		providence, providence, providence
160.589UK	5 Litre	Premium fog fluid	Clear	Slow	Very high	Excellent	Opaque White	
160.592UK	1 Litre	 Low level fog fluid 	Clear	Slow	Highest	Excellent	Opaque White	160.447UK
1100 6701 IK	June	Fog maching cleaner	Clear		Extends life of v	Extends life of vour fog machine		All fog machines
NO01010T	20							
<u>Haze</u>								
Chack Codo	Molumo	Decription	Colour		Res	Results		Eor uco udth
	-			Dispersion	Density	Stability	Haze colour	
160.591UK	5 Litre	5 Litre High quality haze fluid	Close	Slow	High	Good	Thick white	11297 031 XI 160 7501 X 160 760 X 100 160 160 160 160 160 160 160 160 160
160.591UK	5 Littre	5 Littre Eco haze fluid	CIEG	Medium	Medium	Good	White	100-4700V, 100-4720V 100-4020V, 100-4020V
Fog								
Stock Code	Volume	Description			Res	Results		For use with
160.650UK	20ml	Coconut fog fragrance						
160.651UK	20ml	Mint fog fragrance						
160.652UK	20ml	Vanilla fog fragrance			A date for another	the for as have		20ml – El itro for or here flitid
160.653UK	20ml	Tropical fog fragrance			Auto Ballage	Auto II agrance to tog of flaze		בטווון = 2 בונדיב וספ טו חמביב ווחומ
160.654UK	20ml	Strawberry fog fragrance						
	1		-					