

KRK Systems

Mounting Adaptor for VXT 4/6/8



- attaches to speakerstand/wallmount with pipe $\varnothing 35\text{mm}$
- with suitable screw connections for VXT 4/6/8
- easy handling

SAFETY INSTRUCTIONS


- Use only with KRK VXT 4/6/8.
- Inspect bolted assemblies regularly.
- Only for use with proper stand/wallmount (35mm pipe with correct load capacity) and correct installation (level floor surfaces, proper wall mounting, etc.)
- Check speaker threads to ensure attachment screws are not cross-threaded.
- For indoor use only.
- ATTENTION: VXT4 weighs 6.2kg, VXT6 weighs 10.9kg, VXT8 weighs 15.6kg. Ensure that adequate wall support (joists, wall anchors, etc.) or floor stand capacity exists to support the weight of these speakers. For use only by trained installers.

MANUAL


1. Select suitable screw connection.

- VXT8: 4x M8x20 screws
- VXT6: 4x M6x16 screws
- VXT4: 2x M6x16 screws


2. Attach plate to VXT-hole-pattern and fix it with a suitable screw.
Do not over-tighten or cross-thread the screw, as this could result in a loose attachment of the speaker to the stand.




3. Loosen lock-screw (a) until thread is out of inner tube.



4. Place the VXT with the attached mount onto an appropriate wall or floor stand.
Please see: Safety Instructions.



5. Tighten lock-screw (a) again.



6. VXT - new adjustment:
- Loosen lock-screw
- Turn VXT in desired direction
- Tighten lock-screw

CONTROL, MAINTENANCE, CLEANING

- Inspect bolted assemblies regularly.
- For cleaning it is recommended to use a slightly damp cloth and a non-abrasive cleaner.

(D) DEBUGGING : (C) CLEARANCE

- D: Tube doesn't apply to stand/wallmount (too big/small).
- C: Check stand/wallmount: a 35mm pole is necessary.
- D: Speaker is not secure on the mount.
- C: Check screws. They should be the correct size and adequately tightened.
- C: Check speaker threads to make sure the screw is not cross-threaded or stripped.

SPECIFICATIONS

Material	Tubes, plate - steel, black-powdercoated Screws - steel, zinc
Load	VXT 4/6/8
Dimensions	W x D x H: 150 x 150 x 104 mm Pipe: Inner circle ~ 36mm
Weight	0,9 kg

KRK Systems

Boxenflansch für VXT 4/6/8




- aufsteckbar auf Boxenstative/Wandhalterungen mit Rohr \varnothing 35mm
- mit passenden Schraubensätzen für die Modelle VXT 4/6/8
- einfache Handhabung

SICHERHEITSHINWEISE


- Ausschließlich zur Aufnahme der Modelle VXT 4/6/8.
- Prüfen Sie in regelmäßigen Abständen die Festigkeit der Installation.
- Geeignetes Stativ/Wandhalterung verwenden (Rohr \varnothing 35mm, ausreichende Tragkraft) und ordnungsgemäß aufstellen (ebener Untergrund, tragfähige Wand etc.).
- Gewinde der Lautsprecher prüfen.
- Vor Nässe schützen.
- BEACHTEN: VXT4/6/8 wiegen 6,2/10,9/15,6 kg; beim Aufsetzen auf das Stativ bzw. die Wandhalterung empfiehlt es sich mit zwei geeigneten Personen arbeiten.

AUFBAUANLEITUNG


1. Passenden Schraubensatz zurechtlegen.
 - VXT8: 4x M8x20
 - VXT6: 4x M6x16
 - VXT4: 2x M6x16
2. Platte auf das Lochbild der VXT legen und Schrauben mit entsprechendem Schlüssel eindrehen.




3. Durch Losdrehen der Klemmschraube (a) sicherstellen, dass das Gewinde nicht ins Innere des Rohres ragt.



4. VXT mit Rohrstützen voran auf das Stativ bzw. die Wandhalterung setzen; siehe SICHERHEITSHINWEISE.



5. Klemmschraube (a) wieder festdrehen.



6. VXT neu ausrichten: Klemmschraube lösen, VXT in gewünschte Richtung drehen, Klemmschraube wieder festdrehen.



PRÜFEN, INSTANDHALTEN, REINIGEN

- Regelmäßig Festigkeit der Schraubverbindungen überprüfen.
- Reinigen mit einem leicht feuchten Tuch und nicht scheuerndem Reinigungsmittel.

(F) FEHLERSUCHE : (B) BESEITIGUNG

- F: Rohrstützen passt nicht auf Stativ (zu groß/zu klein)
 B: Stativrohr prüfen: \varnothing 35mm erforderlich
- F: Lautsprecher wackelt auf dem Boxenflansch
 B: Halbrundkopfschrauben prüfen/nachziehen
 B: Gewindebohrungen im Lautsprecher prüfen

TECHNISCHE DATEN

Material	Rohre, Boxenplatte - Stahl, schwarz gepulvert Schrauben - Stahl, verzinkt
Traglast	VXT4 (6,2 kg), VXT6 (10,9 kg), VXT8 (15,6kg)
Abmessungen	B x T x H: 150 x 150 x 104 mm, Rohrstützen: Innen \varnothing 36mm,
Eigengewicht	0,9 kg

KRK-Systems, 9340 DeSoto Ave. Chatsworth CA 91311
<http://www.krksys.com>