


**ACTIVE SPEAKER  
OPERATION  
MANUAL**

Congratulation to you! Thank you for your purchase of our company's Active Speaker. Please read the manual carefully before using the product. The power amplifiers are designed for the public address system and suitable for hotel, shop, church, garden and other buildings.

## 1: Rear Panel Instuction



- 1:Volume control
- 2:Treble control
- 3:Bass control
- 4:AUX input
- 5:Speaker-out
- 6:Power switch
- 7:AC fuse
- 8:AC power in

## 2: Power Amplifier Technical Specification:

|                       |                      |
|-----------------------|----------------------|
| Technical date        |                      |
| Output power          | W(RMS)               |
| Frequency response    | -3dB(20Hz-20KHz)     |
| THD at 1KHz           | less than 1%         |
| Input                 | -10 dB(245mv)5k ohms |
| Outputs,speakers      | 4-8 Ohms             |
| Signal-to-noise ratio | >80dB                |
| Power supply          | AC220V/110V 50Hz     |
| Dimensions W*H*D      | 248*183*164mm        |

## 4: Features Instructions

This amplifiers are designed for the public address system.

### Features:

- >All the device of this series operate on 220V AC.
- >The speaker outputs are available as 4-8 ohms low-impedance outputs.

## 5: Precaution:

- A:Read all documentation before operating the equipment.  
Retain all documentation for further reference.
- B:Keep away from high temperature object,damp,dense dust and powerful electromagnetic place.
- C:The equipments generate some heat in using,so leave over 10cm empty space at both sides, 2cm empty space upside.
- D:Always operate the equipments with the AC ground wire connected to the electrical system ground.
- F:Please turn off the power switch when pull off the power cable and signal cable or select the input mode switch.
- G:Never clean the products by organification, clean it by soft cloths.