

# Forte DAW Control

---

## User Guide

# Supported DAW's and Controls

Please note that your DAW must be selected (in focus) and DAW Control Icon lit on the Forte Hardware to use DAW control.

Warning: Using two DAWs simultaneously may result in Forte DAW Control not performing as expected.

## Cubase 6

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Record	Press	Num*
	Horizontal Zoom	Rotate	H/G
	Mouse Scroll	Rotate	Mouse Scroll

## Logic 9 Pro

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
OSX	Play/Stop	Press	Spacebar
	Record	Press	R
	Horizontal Zoom	Rotate	Ctrl+alt+right/ Ctrl+alt+left
	FFW/RW	Rotate	./,
	Vertical Zoom	Rotate	Ctrl+alt+up/ Ctrl+alt+down
	Mouse Scroll	Rotate	Mouse Scroll

## Pro Tools 10

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Zoom	Rotate	Ctrl(cmd)+]/Ctrl(cmd)+[
	*Keyboard Focus Zoom (AZ-Zoom)	Rotate	t/r
	FFW/RW	Rotate	Num1/num2
	Mouse Scroll	Rotate	Mouse Scroll

When using Forte DAW Control with Pro Tools there are 2 zoom options. If you are using a Keyboard with input language other than English please ensure that "Keyboard Focus" is engaged in Pro Tools and "AZZoom" is selected in Forte DAW control.

## Ableton Live 8

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Change View	Press	Tab
	Horizontal Zoom	Rotate	Num+/num-
	Start Point	Rotate	Right/left
	Up/Down	Rotate	Up/Down
	Mouse Scroll	Rotate	Mouse Scroll

## GarageBand

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
OSX	Play/Stop	Press	Spacebar
	Record	Press	R
	Horizontal Zoom	Rotate	Ctrl+alt+right/ Ctrl+alt+left
	FFW/RW	Rotate	Right/left
	Mouse Scroll	Rotate	Mouse Scroll

## Studio One 2

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Record	Press	Num*
	Horizontal Zoom	Rotate	e/w
	FFW/RW	Rotate	Num+/num-
	Vertical Zoom	Rotate	Shift+e/shift+w
	Mouse Scroll	Rotate	Mouse Scroll

## FL Studio 10

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows	Play/Stop	Press	Spacebar
	Horizontal Zoom	Rotate	Page Up/Page Down
	FFW/RW	Rotate	Num*/num/
	Mouse Scroll	Rotate	Mouse Scroll

## Sonar X1

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows	Play/Stop	Press	Spacebar
	Record	Press	R
	Horizontal Zoom	Rotate	Ctrl+Right/ Ctrl+Left
	Vertical Zoom	Rotate	Ctrl+Up/ Ctrl+Down
	Mouse Scroll	Rotate	Mouse Scroll

## Reaper

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Record	Press	Ctrl(cmd)+R
	Horizontal Zoom	Rotate	=/-
	Vertical Zoom	Rotate	Ctrl+Shift+Up/ Ctrl+Shift+Down
	FFW/RW	Rotate	Ctrl(cmd)+Right/Ctrl(cmd)+Left
	Mouse Scroll	Rotate	Mouse Scroll

## Reason 6

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Record	Press	Num*
	Horizontal Zoom	Rotate	H/G
	FFW/RW	Rotate	Num8/num7
	Mouse Scroll	Rotate	Mouse Scroll

## iTunes

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows/OSX	Play/Stop	Press	Spacebar
	Volume	Rotate	Ctrl(cmd)+up/Ctrl(cmd)+down

## Windows Media Player

PLATFORM	FUNCTION	CONTROL ACTION	SHORTCUT
Windows	Play Track	Press	Return
	Select Track	Rotate	Ctrl+up/Ctrl+down