

KAM

INSTRUCTION MANUAL

LS03 STAND

Portable laptop stand

M A N U A L V E R S I O N 1 . 0

06.05.10

Ergonomic design for easy laptop access
Designed for musicians and DJs
Will also support FX or lighting controller
Allows airflow around laptop that prevents overheating
Extensions included for most sizes of laptop
Adjustable height and width
Removable and adjustable second shelf
Secondary shelf for outboard FX units, keyboards, etc

For the latest instruction manual updates and information on the entire Kam range visit:

www.kam.co.uk

Kam products are manufactured by: **Lamba plc**, Unit 1, Southfields Road, Dunstable, Bedfordshire, United Kingdom LU6 3EJ
Telephone: (+44) (0)1582 690600 • Fax: (+44) (0)1582 690400 • Email: mail@lambapl.com • Web: www.lambapl.com

If this product is ever no longer functional please take it to a recycling plant for environmentally friendly disposal.


Due to continuous product development, specifications and appearance are subject to change.

© Copyright Lamba plc 2010. E&OE.

Thank you for purchasing this product, we are sure that it will serve you for many years to come.

Please read these instructions carefully to familiarise yourself with the assembly of this stand. After you have read the instructions, please retain them for future reference. This stand has been tested at the factory before being shipped to you, any modification carried out may invalidate its warranty. Please unpack your stand carefully, your new product should reach you in perfect condition. Please check that no damage has occurred during transit. If any damage is found, please contact the retailer you purchased it from immediately.

Parts You will receive all of parts below.



Basic assembly

Take one of the upper supports (1) and place it over the **outside** of one of the lower supports (2). Align the upper support holes with the lower support holes to obtain the desired height. Screw a knob (3) through the mounting holes and screw into one of the crossbars (4). Repeat with the second crossbar but make sure that it is at least two holes apart from the first crossbar. To increase the width of the stand, screw in spacers (5) into both of the crossbars. Join the other two supports and screw into the crossbars using the remaining two knobs. Tighten all knobs to minimize wobble.

Adjustable shelf assembly

Place the smaller section of shelf (6) over the nuts of the larger section of shelf (7). Screw in the locking knobs (8) to join the two sections. Clip the assembled shelf over a crossbar of the stand. Adjust the width of the shelf by loosening the locking nuts and pulling the two parts of the shelf apart. Ensure that the outer edges of the shelf bracket (9) are on the outside edge of the basic stand.

