

Mini Bubble USB

Bubble Machine

Item ref: 160.561UK

User Manual



Caution: Please read this manual carefully before operating
Damage caused by misuse is not covered by the warranty



Introduction

The QTX Mini Bubble USB is a compact yet powerful bubble machine that produces an impressive amount of bubbles for its size. Powered safely via the included USB lead and a compatible socket (not supplied), this lightweight unit is simple to setup and use and perfect for parties and small events. The sturdy plastic construction and carry handle make it easy to transport or hang on a lighting rig if required.

Unpacking

Your Mini Bubble USB should reach you in good condition and should be supplied with a 2m USB power lead, spare bubble wheel and user guide. If there are any signs of damage or items missing from the packaging, please contact your dealer immediately.

Warning

To prevent risk of fire or electric shock, do not expose electrical parts to rain or moisture. If liquids are spilled on the housing or through the vents, disconnect the power, allow the unit to dry out and have it checked by qualified personnel before further use. Avoid any impact, dropping or extreme pressure to the housing. No user serviceable parts inside - do not open the case. Refer all servicing to qualified service personnel.

Placement

The Mini Bubble USB has an upright fluid tank and should always be operated in an upright position. Choose a position where the bubble output is facing the area to be filled. Ensure easy access to the rear panel and to

the bubble fluid tank for refilling and cleaning. When moving the unit around, take care not to spill the contents of the tank inside the machine.

Safety

- Always use the correct USB DC5V 2A power supply to ensure the unit works to its maximum capacity.
- Please ensure the unit is placed as far way from the mains socket as possible, and that the bubble output is facing away from the area.

Cleaning

- Use a soft dry or slightly damp cloth to clean the casing
- Do not use strong solvents for cleaning the unit
- Empty contents and rinse the bubble fluid tank after each use
- Unplug the unit from mains power then use a vacuum or air compressor and a soft brush to remove dust collected on external vent at the back of the unit

Set up and operation

The Mini Bubble USB requires bubble fluid to produce the effect.

It is recommended to use qtx bubble fluid for best results (160.574UK, 160.575UK)

For bubbles that glow in UV light, qtx UV bubble fluid may be used (160.576UK, 160.577UK)

- Position the unit on a stable surface or mount upright using the integral bracket.
- Carefully fill the fluid reservoir with the required fluid ensuring you completely cover the bottom wand and taking care not to spill on electrical parts of the machine.
- Connect the supplied USB power lead to the Type-C socket on the rear panel.
- Connect the USB Type-A socket end of the power lead to a suitable DC5V 2A USB power supply and switch on.
- Turn the bubble flow on and off using the Power rocker switch on the back of the unit.
- To replace the bubble wheel, grab by the centre and pull firmly towards you. Push the replacement wheel onto the centre spindle and push firmly towards the unit.

Specifications

Power supply	DC/5V 2A (USB Type-C lead supplied)
Power consumption	2W
RPM	32
Number of wheels	1
Number of wands per wheel	8
Fluid capacity	350ml (approx. 45 minutes use)
Dimensions	140 x 120 x 230mm
Weight	700g



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines

Errors and omissions excepted.

Copyright© 2024 AVSL Group Ltd, Unit 2 Bridgewater Park,
Taylor Road, Trafford Park, Manchester. M41 7JQ.

AVSL (Europe) Ltd, Unit 3D North Point House,
North Point Bus. Park, New Mallow Road, Cork, Ireland.