

LED INTERLINK LIGHT EFFECT OPERATING INSTRUCTIONS

LED Interlink light is a novelty lamp which includes different coloured LED modules. Each LED module has a reflector and 49 LEDs. The product has a chasing flashing function and also a sound response sensor.

-FOR INDOOR USE ONLY!

-THIS PRODUCT IS NOT INTENDED FOR CHILDREN UNDER 10 YEARS OF AGE.

-AVOID DIRECT EYE CONTACT WHEN THE PRODUCT IS TURNED ON. LED'S ARE VERY BRIGHT AND MAY CAUSE INJURY TO YOUR EYES.

1.Contents of Packaging

- 1 LED Interlink Light
- 1 Power Adapter
- 1 Instruction sheet

2.Special features

LED Interlink lights has 49 LED's per module
Chasing flashing function
Sound response sensor and sensitivity adjustment

3.Attention

Read the operating guidelines before using the light.
The operating instructions are a product component. These contain important advice on operating and handing the device.
Always keep the enclosed operating instructions for future reference!

4.Correct operation

This product may only be used indoors; all contact with damp moisture and humidity should be avoided. Using the device other than as specified may cause damage to the product, and is also linked to potential dangers such as short-circuits, fire, or electric shock. Do not change, adapt or open the product in any way!

5. Safety guidelines

The manufacturer will not be liable in the event that personal injury or consequential damage results from failure to observe these safety guidelines and the incorrect use of the device.

- Never attempt to open the device.
- Repairs should only be carried out by qualified repair personnel.
- Ensure that the device is ventilated. Never cover it during operation.
- Avoid subjecting the device to excess stress or strain.
- Do not expose the device to high temperatures, strong vibrations or high levels of dampness or moisture.
- Only use the components included with the product in conjunction with the device.
- Keep the device out of the reach of children and animals.
- The Interlink lights are only suitable for use indoors. Please protect the device from damp and moisture.
- The device can be considered unsafe in the event that:
 1. The lighting controls or power adaptor exhibits visible damage,
 2. The device no longer functions,
 3. The device has been placed under excess stress or strain during transportation.

6. Operation

1. Connect the power adapter to the control unit.
2. Then, switch on the device using the "ON/OFF" switch.
3. You can now select the "SPEED" or "MUSIC" functions using the two adjustable controls on the front of the control module.
4. To activate device's chasing function, turn the "MUSIC" control to the left (selecting the first possible setting). You can now use the "SPEED" control to adjust the flashing speed.
5. The "Sound response" function is activated using the left control. The light spots now react both to light sequence and sounds. You can adjust the microphone's sensitivity. Select the desired flashing speed using the "SPEED" control and adjust the integrated microphone's sensitivity level using the "MUSIC" control. The light spots will now flash according to the intensity of the sound near the unit.

7.Care

Before cleaning the unit, disconnect it if from other components; do not use aggressive cleaning agents. Use a clean cloth to wipe any dust or dirt from the product. We are not liable for damage arising from incorrect handling, improper use or wear and tear. We reserve the right to make technical modifications.

8.Technical data

LED Interlink Lights

Operating voltage:

-Power adapter input: 240Vac, 50Hz

-Power adapter output: 14Vdc, 300mA

LED's: 49 LED's per module (red/blue/yellow/green)